

Ice Zapper® 2 Dish Heater

Intended for use on the rear surface of a metal satellite dish with a smooth back.

NO TOOLS REQUIRED FOR INSTALLATION.

WARNING: Make sure your heater is plugged into an outlet approved for outdoor use.

Do not plug in until the heater has been installed on your dish.

INSTALLATION AND USE OF ICE ZAPPER® SATELLITE DISH HEATER

Step 1

Lay out the Ice Zapper® to check for placement before affixing to dish.

Step 2


Thoroughly clean the surface of the dish where the Ice Zapper® will be installed.

Step 3

Carefully peel off the protective slip sheet from the pressure sensitive adhesive on the Ice Zapper®.

Apply the two heater patches on either side of the mounting bracket and press firmly into place. Add a drip loop in the electrical cord as shown in the illustration and secure with the included zip tie.

NOTE: While the Ice Zapper® can be applied in cold weather, the first time the dish is warmed from either the sun or the heater itself, you will need to reapply pressure and smooth the surfaces.



The unit is fully operational once installed.

Specifications

| | |
|---------------------------|--|
| Voltage | 120 volt AC power cord UL and CE compliant |
| Wattage | 120 watts |
| Intended Use | UL and CE approved for outdoor use |
| Temperature Range | -60° F (-45° C) to 475° F (264° C) |
| Maximum Amperes | 1 Amp |
| Material and Construction | Silicone sheet material, two sided with imbedded resistance wire. Pressure sensitive adhesive |
| Warranty | 1 year warranty on workmanship and materials |